



[Knowledgebase](#) > [Moto Watch 100](#) > [Troubleshooting & Setup](#) > ["Always On" Mode on Your Watch: A Guide](#)

## "Always On" Mode on Your Watch: A Guide

Inas B. - 2025-10-08 - [Troubleshooting & Setup](#)

The **Always On** feature keeps your watch face visible at all times but uses more battery. Here's how to enable or disable it:

### Enable "Always On"

#### Method 1: Settings Menu

1. Press the top button to access the home screen.
2. Tap **Settings**.
3. Go to **Display** → **Screen On**.
4. Select **Always On**.

#### Method 2: Quick Settings

1. Swipe down from the top of the watch screen.
2. Tap the bottom-left icon (watch with four lines).

A white background confirms that **Always On** is active.

### Disable "Always On"

#### Quick Settings Method:

1. Swipe down from the top of the watch screen.
2. Tap the bottom-left icon again.

A gray background indicates that **Always On** is turned off.

**Tip:** Use this feature as needed to balance convenience and battery life.