

[Knowledgebase](#) > [Moto Watch 40](#) > [Troubleshooting & Setup](#) > [Moto Watch 40 Not Vibrating](#)

## **Moto Watch 40 Not Vibrating**

Inas B. - 2025-10-10 - [Troubleshooting & Setup](#)

If your **Moto Watch 40** isn't vibrating, follow these steps to fix the issue:

## 1. Check Do Not Disturb (DND) Mode

- **Ensure DND is off:** When Do Not Disturb is enabled, the watch won't vibrate for notifications or alerts.
- Swipe down from the watch face to open **Quick Settings** and check the DND icon.
- Tap the icon to **turn off DND** if it's active.

**Check DND schedule:** Make sure your phone's DND schedule is not active at the current time.

## 2. Adjust Vibration Settings

- Go to **Settings > Vibration** on your watch.
- Set the vibration intensity to **High**.
- Confirm the change when prompted.

Your watch should now vibrate properly for notifications and alerts.