How to Adjust Vibration Intensity on Your Moto Watch 40

Inas B. - 2025-10-10 - Troubleshooting & Setup

You can easily customize the vibration strength on your **Moto Watch 40** to suit your preferences. Follow these steps:

Steps to Adjust Vibration Intensity

1. **Access the Menu**
   Swipe right on the watch face to open the menu.

2. **Go to Settings**
   Scroll through the menu and tap **Settings**.

3. **Select Vibrations**
   Find the **Vibrations** option and tap it.

4. **Choose Intensity**
   You'll see three levels: **Low**, **Medium**, and **High**.
   Select your preferred level to set the vibration strength for notifications.

Customizing the vibration allows your watch to provide feedback that fits your daily routine and comfort.