"Always On" Mode on Your Watch: A Guide

Inas B. - 2025-10-08 - Troubleshooting & Setup

The **Always On** feature keeps your watch face visible at all times but uses more battery. Here's how to enable or disable it:

Enable "Always On"

Method 1: Settings Menu

1. Press the top button to access the home screen.
2. Tap **Settings**.
3. Go to **Display → Screen On**.
4. Select **Always On**.

Method 2: Quick Settings

1. Swipe down from the top of the watch screen.
2. Tap the bottom-left icon (watch with four lines).

A white background confirms that **Always On** is active.

Disable "Always On"

Quick Settings Method:

1. Swipe down from the top of the watch screen.
2. Tap the bottom-left icon again.

A gray background indicates that **Always On** is turned off.

Tip: Use this feature as needed to balance convenience and battery life.