Using Do Not Disturb (DND) Mode on Your Moto Watch 120

Inas B. - 2025-10-10 - Product Features

Do Not Disturb (DND) mode on your Moto Watch 120 allows you to silence notifications, calls, and reduce distractions. While DND is active, you will not receive alerts until it is turned off. Here’s how to enable and customize DND mode.

Enabling Do Not Disturb Mode

Access Quick Settings
Swipe down from the watch face to open the Quick Settings menu.

Enable DND
Tap the DND icon. The icon will turn light blue, indicating that DND mode is active.

> Note: While DND is on, all notifications and calls will be silenced.

Customizing Do Not Disturb Mode

Access Quick Settings
Swipe down from the watch face to open Quick Settings again.

Open Settings
Tap the **Settings** icon (gear symbol).

Navigate to Do Not Disturb
Select **“Do Not Disturb”** from the settings menu.

Customize Options

- **All Day:** Turn DND on or off manually.
- **Schedule:** Set start and end times for automatic DND activation.
- **AOD (Always On Display):** Choose whether the display remains active during DND mode.

By customizing these settings, your Moto Watch 120 only provides notifications when you want them, seamlessly fitting into your daily routine.