

Knowledgebase > Moto Watch 70 > Troubleshooting & Setup > Adjusting Your Moto Watch 70's Display Brightness

Adjusting Your Moto Watch 70's Display Brightness

Inas B. - 2025-10-08 - Troubleshooting & Setup

Customize your Moto Watch 70's display brightness directly from the settings for optimal visibility and comfort.

Customizable Brightness Levels:

• The watch offers **five brightness levels**: 20%, 40%, 60%, 80%, and 100%.

Easy Brightness Adjustment:

- 1. Open **Settings** on your Moto Watch 70.
- 2. Locate the **Brightness** option.
- 3. Tap the plus(+) or minus(-) icons to set your preferred brightness level.

This feature allows you to personalize your display for the best viewing experience, whether in bright sunlight or a dim room.