



[Knowledgebase](#) > [Moto Watch 100](#) > [Troubleshooting & Setup](#) > [Fixing Unit Settings Resets on Your Moto Watch 100](#)

## Fixing Unit Settings Resets on Your Moto Watch 100

Inas B. - 2025-10-08 - [Troubleshooting & Setup](#)

If your Moto Watch 100 keeps resetting preferred units like **Distance, Time, Weight, or Temperature**, you can fix it easily through the Moto Watch app.

### Steps to Fix:

1. **Open the App:** Launch the Moto Watch app on your paired smartphone.
2. **Access Settings:** Tap the **Settings** icon in the top-left corner.
3. **Adjust Units:** Go to **In-App Settings** and choose your preferred units for Distance, Time, Weight, and Temperature.
4. **Sync Changes:** The app will sync your updated units with your watch automatically.

Following these steps ensures your Moto Watch 100 always displays your preferred units correctly.