Moto Watch 40 – Do Not Disturb (DND) Mode

Inas B. - 2025-10-10 - Troubleshooting & Setup

Take control of your focus with the **Do Not Disturb (DND) mode** on your Moto Watch 40. This handy feature lets you silence notifications and alerts whenever you need some uninterrupted time—without missing out on important alarms or activity tracking.

Turn On DND Mode

1. Swipe down from the watch face to open **Quick Settings**.
2. Tap the **DND (crescent moon) icon**.
3. When the icon turns white, DND mode is active—you're ready to focus without interruptions!

Turn Off DND Mode

1. Swipe down from the watch face again to access **Quick Settings**.
2. Tap the **DND icon** once more.
3. The icon will return to its normal state, and you'll start receiving notifications again.

> Tip: Even with DND on, your watch continues to track your activities and alarms still work as usual—so you can enjoy peace of mind while staying on top of your schedule.