



[Knowledgebase](#) > [Moto Watch 40](#) > [Troubleshooting & Setup](#) > [Moto Watch 40 - Do Not Disturb \(DND\) Mode](#)

## Moto Watch 40 - Do Not Disturb (DND) Mode

Inas B. - 2025-10-10 - [Troubleshooting & Setup](#)

Take control of your focus with the **Do Not Disturb (DND) mode** on your Moto Watch 40. This handy feature lets you silence notifications and alerts whenever you need some uninterrupted time—without missing out on important alarms or activity tracking.

### Turn On DND Mode

1. Swipe down from the watch face to open **Quick Settings**.
2. Tap the **DND (crescent moon) icon**.
3. When the icon turns white, DND mode is active—you're ready to focus without interruptions!

### Turn Off DND Mode

1. Swipe down from the watch face again to access **Quick Settings**.
2. Tap the **DND icon** once more.
3. The icon will return to its normal state, and you'll start receiving notifications again.

Tip: Even with DND on, your watch continues to track your activities and alarms still work as usual—so you can enjoy peace of mind while staying on top of your schedule.