Activating Do Not Disturb (DND) Mode on Moto Watch 70

Inas B. - 2025-10-08 - Troubleshooting & Setup

Do Not Disturb (DND) mode on your Moto Watch 70 lets you enjoy uninterrupted moments by silencing notifications and calls.

To Enable DND Mode:

1. From the watch face, swipe down to access Quick Settings.
2. Tap the **DND** icon.
3. The icon will turn white, indicating DND mode is active.

To Disable DND Mode:

- Tap the **DND** icon again to turn off the mode.

By following these steps, you can manage notifications and enjoy quiet time when needed.