



[Knowledgebase](#) > [Moto Watch 70](#) > [Troubleshooting & Setup](#) > [How to Fix Notification Issues on Your Moto Watch 70](#)

# How to Fix Notification Issues on Your Moto Watch 70

Inas B. - 2025-10-08 - [Troubleshooting & Setup](#)

If your Moto Watch 70 isn't receiving notifications, try these troubleshooting steps to restore full functionality:

## Step 1: Ensure Bluetooth Is Enabled

Make sure Bluetooth is turned **on** for both your phone and your Moto Watch 70. Check that the devices are **paired and connected** in your phone's Bluetooth settings.

## Step 2: Check Notification Permissions

1. Open the **Moto Watch Lite App** on your phone.
2. Tap your **Profile icon** (top left).
3. Select your **Moto Watch 70** under *My Devices*.
4. Go to **Phone Permissions** and ensure notifications are enabled for relevant apps (calls, messages, etc.).

## Step 3: Verify Phone Notification Settings

Make sure your phone's **Do Not Disturb** mode is turned **off**. Go to **Settings > Notifications** and verify that app notifications are enabled.

## Step 4: Disable Battery Saver Mode

Battery Saver may restrict background app activity. Disable it to allow notifications to sync.

## Step 5: Restart Both Devices

Restart your **phone** and your **Moto Watch 70** to refresh the Bluetooth connection.

## Step 6: Update the Moto Watch Lite App

Ensure you're using the **latest version** of the Moto Watch Lite app from the **App Store** (iOS) or **Google Play Store** (Android).

## Step 7: Re-pair Your Watch

If issues persist:

1. Go to your phone's **Bluetooth Settings** and tap **Forget Device** for Moto Watch 70.
2. Open the **Moto Watch Lite App** and pair your watch again.

If you still experience problems, please contact our support team at for personalized assistance.